


**CERTAIN-PORE**
**CFN Type**
**Major Applications**

Various water-based solutions


**Example:**  
 Ultrapure water, Chemicals,  
 Water-based dye inks, etc.

**Features**

- Asymmetric hydrophilic polysulfone membrane
- 100% integrity tested

**Advantages**

- Excellent differential pressure vs. flow rate
- Long service life
- High reliability

**Structure**

**Specifications**


Grades	001	002	005	012
Micron Ratings ( $\mu\text{m}$ )	0.1	0.2	0.45	1.2
E.F.A. ( $\text{m}^2/250\text{mm}$ )	0.76	0.76	0.76	0.76
Media	Polysulfone (PSU) Membrane			
Materials Core/Cage/Support	Polypropylene			
End Cap	Polypropylene			
Maximum $\Delta P$	0.49MPa at 20°C (71psi at 68°F)			
Maximum Operating Temp	80 °C (176°F)			
Length	125 / 250 / 500 / 750 mm			
Dimensions O.D.	70.0mm			
I.D.	25.6 (for 0.5) / 26.1 (for F) / 30.0 (for 7) mm			
Adaptable Food Sanitation Standard	All raw materials meet the requirement of FDA 21 CFR *1			

\*If you need further information on specifications (length, end cap type, etc.), please contact us.

\*1 Applicable Gaskets and O-ring materials exclude EPDM.

## Differential Pressure vs Flow Rate

Fluid: Refined Water 20°C (68°F) / Cartridge Length: 250mm



## Ordering Information

Length	Product Type	Micron Rating	Gasket/O-Ring	End Cap Code	Packaging Code
<b>2 5 0 L</b>	<b>-CFN-</b>	<b>0 0 1</b>	<b>V</b>	<b>0</b>	<b>A</b>
125 = 125mm 250 = 250mm 500 = 500mm 750 = 750mm		001 = 0.1 μm 002 = 0.2 μm 005 = 0.45 μm 012 = 1.2 μm	S = Silicone E = EPDM N = NBR V = FKM T = FEP Encapsulated FKM (for 0, 5, 7) PTFE (for F)	F = Flat Gaskets 0 = 2-222 O-Ring 5 = 2-222 O-Ring + Fin 7 = 2-226 O-Ring + Fin	A = 1pc B = 6pcs C = 10pcs F = 25pcs

## End Cap Code



\*The contents of the catalog are subject to change without notice.

\*The performance data listed in the catalog are Typical values obtained under specific conditions based on our tests.

# ROKI GROUP International Pte. Ltd.

6-20-12, Minami-Oi, Shinagawa-ku Tokyo, 140-0013 Japan  
 TEL: +81-3-5764-1131 FAX: +81-3-5764-0681

[www.rokiglobal.com](http://www.rokiglobal.com)

Manufacturing is based on our Quality Management Systems that meet ISO9001 standards.

Scope  
 Design, Development, manufacture, and sales of filter cartridges, housings and filtration equipment.



4th Issue  
 CFN210901E